



KARMANN GHIA DASH INSTALLATION

1968-1969-1979

OLD DASH REMOVAL

- 1.1 UNSCREW ANY EXPOSED HARDWARE, SUCH AS SCREWS AT EACH END OF DASH.
- 1.2 REMOVE NUTS AND WASHERS FROM UNDERSIDE, (8) EACH.
- 1.3 REMOVE DASH AND CLEAN METAL FRAME AREA.

INSTALLATION OF NEW DASH

- 2.1 INSTALL DASH WHEN AIR TEMPERATURE IS 70 OR ABOVE. THE MATERIAL IS FLEXIBLE AND MORE WORKABLE WHEN WARM. IT WILL INSTALL EASILY AND PRECISELY.
- 2.2 PLACE NEW DASH OVER METAL FRAME AND PRESS WHITE, PLASTIC STUDS THROUGH HOLES IN FRAME.
- 2.3 OBTAIN THE SMALL PACKAGE OF WASHERS YOU RECEIVED IN BOX. NOW, PRESS THESE OVER STUDS. THIS IS A MODERN FASTENING SYSTEM, AND REQUIRES NO SCREWING.
- 2.4 RE-INSTALL ANY EXISTING SCREWS, WHICH MAY HAVE BEEN PRESENT, AND YOUR INSTALLATION IS COMPLETE.

TO ENSURE LUSTER AND PRESERVATION OF YOUR NEW DASH, USE OF ARMORAL OR EQUIVALENT IS RECOMMENDED.